

FAQ & Troubleshooting

- 1- Will a Japanese console work in the US or in PAL territories and viceversa?

Yes, the RePS2 adapter works for all FAT revisions from all regions.

- 2- Is this compatible with HDDs and softmods such as FreeMcBoot?

Yes.

- 3- Will this solve my console not reading discs?

Nope, chances are that the laser need replacement/cleaning.

- 4- I have installed the RePS2, I get the red standby LED but the console does not power up.

Your 12v AC adapter is not able to deliver the Amps needed for the console to start up. Avoid cheap low-quality adapters and use one of the recommended ones.

- 5- My console switches on but I now get noise on the screen.

Use a good quality AC adapter and/or make sure your AV cable is decent (shielded if possible).

- 6- What happens if I use a super cheap 12v adapter or if the adapter has less than 5A?

Chances are you'll get noise and/or that your console won't start. The AC adapter transforms AC 220v or 110/115v to DC 12v, whereas the RePS2 filters the 12v into the PS2 PCB. This makes the AC adapter an essential part of the circuit.

Any Qs, use the contact form at: rexisnexus.com

Rexus 2021